Sump Pump Operating Times During Power Outage


TABLE 1

			Single	Battery Ope	eration	
			Pump Curren	t Rating - 6A	Pump Cumen	t Rating - SA
			Low Duty Cycle	High Dusy Opde	Low Duty Opdie	High Duty Opdie
Dettery Stor			Manager 1 release off	20 meanings 1 minute of	I resistant II	Hamedon Labore ell
Bettery SCI Group Sibe	Typical A Hr.	No. of Batteries	Hours	Hours	Hours	Hours
24	80	1	25.3	8.4	16.9	3.6
27	90	1	28.5	9.5	19.0	6.3
29	95	1	30.1	10.0	20.1	6.7
30	110	1	34.8	11.6	23.2	7.7
31	125	1	39.6	13.2	25.4	8.8
4D	200	1	63.3	21.1	42.2	14.1
8D	245	1	77.6	25.9	51.7	17.2

TABLE 2

			Multiple	Battery Open	rtion for increa	and Time
			Pump Curren	e Rading - 6A	Pump Current	t Rating - SA
Bettery Site			Low Day Cycle 10 months of 1 minutes of	High Date Cycle 10 seconds on 1 release off	Law Date Cycle 18 seconds on 19 minutes off	High Duty Cycle 10 seconds on 2 release off
Bettery BCI Group Stre	Typical A Hr.	No. of Setteries	Hours	Hours	Hours	Hours
24	80	2	50.7	16.9	33.8	11.3
27	90	2	57.0	19.0	38.0	12.7
29	95	2	60.2	20.1	40.1	13.4
30	110	2	69.7	23.2	46.4	15.5
31	125	2	79.2	26.4	52.8	17.6
24	80	3	76.0	25.3	50.7	16.9
27	90	3	85.5	28.5	57.0	19.0
29	95	3	90.3	30.1	60.2	20.1
30	110	3	104.5	34.8	69.7	23.2
31	125	3	118.8	39.6	79.2	26.4

How to Connect Multiple Batteries



Why You Need a Pump Sentry™ Battery Backup System

With all the things to worry about during a power outage, the last thing you need is a flood in your now pitch-black basement. When the power finally does return, you look in horror as you see your personal belongings floating, cardboard boxes saturated and soggy, and ruined electronics. The Pump Sentry™ product line is designed to give you the peace of mind you want during a rain storm that leads to a power outage. When the power goes out, Pump Sentry™ automatically switches to battery power and keeps your main sump pump running and your basement dry. When power returns, Pump Sentry™ automatically starts recharging the battery, preparing for the next power outage.

FEATURES:

- Plug & Play Can be installed with any sump pump in under 10 minutes.
- No need to install an additional pump or re place the existing one
- · Clean Pure Sine Wave Output.
- Keeps sump pump operating at peak level when power is lost
- Durable not a throw-away appliance –
 10 year life expectancy.
- · Specifically designed for pump operation
- · Made in the U.S.A. Locally serviceable
- 3 Year Warranty

Manufactured in the USA by:



P.O. Box 2266, 78 Ethan Allen Drive S. Burlington, VT 05403

Tel: 802-865-8388 • Fax: 802-865-8389 email: sales@secamerica.com • Internet:www.secamerica.com

Printed in The USA

Copyright June 2022

WHEN THE POWER GOES OUT... ©

Keep Your Basement Dry!



Automatic Battery Backup
For
Submersible Pumps
Pedestal Pumps
Sewage Pumps



www.secamerica.com

Easy Installation in Under 10 Minutes

1) Mount on a shelf or to a wall (Fig. 2):

Pump Sentry conveniently mounts to the wall or a shelf. It should be mounted at close proximity to a grounded AC outlet, provided the AC cord from the Pump Sentry will reach it.



2) Make Connections (Fig. 3):

- Make sure the On/Off switch is in the OFF position.
- b) Connect battery to Pump Sentry[™] using supplied cables
- Plug your Pump into Pump Sentry's AC outlet.
- d) Plug the Pump Sentry into a 120 volt AC outlet.
- e) Turn the On/Off switch to ON. (Fig. 3A)





Fig. 3A


ELECTRICAL SPECIFICATIONS	Model 933	Model 1733
Input Volts	120 VAC; 60Hz	120 VAC; 60Hz
Output Wave Shape (backup) and	Low Distortion Sine Wave with	Low Distortion Sine Wave with
Output Wave Shape (on line)	Distortion <3% into resistive loads	Distortion <3% into resistive loads
Maximum Continuous Output Power	1200 Watts	1800 Watts
Start Up Surge Capacity	30 A	45 A
Audio Indicator		
Audi ble Alarm - Imminent Shutdown	When battery has declined < 10.8V	When battery has declined < 10.8V
VISUAL LED's	Conditions	Conditions
Active when lit - LED (A)	Power present at output receptacle.	Power present at output receptacle.
Charging LED Indicator (B) - Blinking	Blinking When Charging	Blinking When Charging
Charging LED Indicator (B) - Fully ON	Battery is full-charging suspended	Battery is full-charging suspended
Replace Battery LED Indicator (C) - Fully ON	Battery is degraded from long term use	Battery is degraded from long term use
Dimensions & Weight		
Weight	17/7.7 (lb./Kg.)	22/10 (lb./kg.)
Size	18.5×8.6×3.5/47×22×9 (in/cm.)	22 x 8.6 x 3.5 /56 x 22 x 9 (in./cm.)
Mounting Hole Centers	12×7.9 / 30.5×20 (ln/cm.)	17×8.2 / 43.5×21 (in/cm.)
Supplied Cables	BC-42/4 ft. #2 gauge	BC-42/4 ft. #2 gauge

BATTERY INSTALLATION

Installation of batteries should be performed or supervised by persons knowledgeable about battery handling precautions. Install batteries in a convenient remote location particularly inaccessible to children and flammable fluids. For more information, read the Pump Sentry™ owner's manual.

Only batteries conforming to Battery Council International (BCI) group size 29 or larger are recommended. Only lead acid or AGM batteries are designed for the type of service which Pump Sentry™ requires. INSTALL ONLY deep cycle batteries. The marine-variety is acceptable. DO NOT use car batteries.

Up to three batteries maybe connected as shown in Figure 4 to increase back up time. (See Table 1 and Table 2).



BATTERY BOX

Your selected battery(ies) should be installed in a high quality plastic or metal battery box with a lid that is designed for the box.



Figure 5